



Natural Resources
Canada

Ressources naturelles
Canada

Cold flow investigations of a plug flow reactor with internal recirculation for pressurized chemical looping

Scott Champagne, Amanda Alain, Nicole Bond,
Christopher McIntyre, Stephen Montero, Robin Hughes

August 5, 2021

Canada


Outline

- Pressurized chemical looping
- Plug flow reactor with internal recirculation (PFIR)
- Design approach & data needs
- Circulation rate measurement challenges
- Method evaluation
- Status & future work




Pressurized Chemical Looping (PCL)

- Technology for burning fuels to produce **heat** with inherent separation of CO₂
 - Oxygen carrier composed of metal oxides for redox reactions
 - Direct contact between fuel and air is avoided
 - O₂ is transferred *via* an **oxygen carrier** (OC)
 - High purity CO₂ product achieved via drying of flue gas stream
 - Achieved with dual fluidized beds (air reactor and fuel reactor)
- CanmetENERGY is currently developing a 600 kWth pilot plant
- Technology to provide zero-emission heat or hydrogen to industry



PFIR

- CanmetENERGY & Hatch Ltd. are collaborating on the design of the PCL reactor system
- Hatch's patented plug flow reactor with internal recirculation (PFIR) is a good fit for PCL
 - Annular reactor segmented into 2 bubbling fluidized beds:
 - Air reactor and fuel reactor
- Enables large flowrates of solids between the two reactors
 - Move oxygen and heat between air and fuel reactors
 - Solid movement enabled by angled jets at the distributor
- Single reactor vessel reduces capital costs and process complexity



Adham, Kamal; Harris, Christopher; Kokourine, Alexandre. Plug flow reactor with internal recirculation fluidized bed. WO2015/188267 A1, World Intellectual Property Organization, 17 December 2015.





Natural Resources
Canada

Ressources naturelles
Canada

Canada

Design Approach

- Three pronged approach to reactor design incorporating modeling and experimental validation:
 - Two-phase theory 1D reactor model
 - Kinetics, gas/solid reaction models
 - Barracuda CPFD
 - Fluidized bed performance, geometry
 - Cold flow experimentation
 - Model validation, performance data




```

141
142
143     def massBalance_bed(self, z, molarFlows,
144
145



```

total molar flow in bubble
 flows[0] + molarFlows[1] +
 flows[3] + molarFlows[4] +



The Cold Flow Model

- Large cold model under development to optimize PFIR design for PCL process
 - Generate data to validate CPFD and reactor models
- Cold model built out of plastic to minimize signal degradation for particle tracking methods
- Key performance indicators:
 - Circulation rate of bed material between air and fuel reactors
 - Residence times of bed material in each reactor
 - Solids mixing
 - Gas mixing at the reactor boundaries
- Test conditions:
 - Superficial velocity: 0.0 - 0.85 m/s
 - Bed material: Aluminum oxide, 350 μm , 3950 kg/m³
 - Atmospheric temperature and pressure




Circulation Rate Measurement

- Priority parameter for model validation and hot pilot design
- Objective:
 - Select a measurement technique for the cold flow model to:
 - Measure circulation rate of bed material between two reactors
 - Measure residence time distribution in each reactor
- Challenges:
 - Measurement devices cannot interfere with solid and gas flow patterns in the PFIR
 - No loop seals, return legs or other exterior flow control devices
 - 'Bucket method' not feasible
 - Dense bed material ($\sim 4000 \text{ kg/m}^3$) and high circulation rates
- Particle tracer methods:
 - Several techniques (magnetic, radioactive, inductance, etc.)
 - No clear front runner given application




Particle Tracking Concept

- Inject a tracer particle at the solids inlet flow plane
 - Single particle vs. multiple particles
- Measure signal on inlet sensors
- For single particles:
 - Monitor position of tracer with multiple sensors
 - Allow particle to transit between reactors many times to get RTD
- For multiple particles:
 - Monitor concentration of particles at outlet plane
 - Collect particles and re-inject



Inductance Particle Tracking

- Track ferromagnetic or conductive tracer particles using an inductor coil
 - Tracer candidates: steel, aluminum, iron
- Concentration of tracer particles in the sensing area of the coil correlates to coil inductance
 - Tracer changes magnetic permeability in region near coil, changing the field and therefore the coil's inductance
- Coils typically installed around the exterior or return legs or loop stand pipes
 - Field most dense in the interior of the coil, producing the strongest signal
 - Lack of solid transfer systems in PFIR is a challenge



<https://www.nde-ed.org/EducationResources/CommunityCollege/MagParticle/Physics/CoilField.htm>





Natural Resources
Canada

Ressources naturelles
Canada

Canada

Inductance Particle Tracking

- Flat, printed circuit board coils investigated
 - Based on Texas Instruments inductance-to-digital converters
 - Multiple sensors can be mounted at the inner and outer perimeter of the PFIR annulus
- Experiments completed to determine coil design requirements and performance of various tracer candidates



Sensor
frequency


$$f = \frac{1}{2\pi\sqrt{LC}}$$

Inductance Capacitance




Inductance Particle Tracking

- Tracer: 430L stainless steel
- Bed material: alumina zirconia
- Fluidizing gas: air
- Velocity range: 0-3 U/Umf



CT-310 CT-311 CT-312 → Injection



Natural Resources
Canada

Ressources naturelles
Canada

Canada

Inductance Particle Tracking

Advantages

- Tracer particles can be selected to have similar fluidization behaviour to bed material
- Flat coils integrate well into the PFIR geometry
- May be able to measure bubble properties
- Measure concentration of tracer to allow rapid RTD measurement

Challenges

- Bed material must be non-magnet and non-conductive to minimize signal noise
- Large amount of tracer required to achieve significant signal to noise ratio
- Significant development time required to deploy the PCB coil sensors



Magnetic Particle Tracking

- Magnets are used as tracer particles and their position and orientation is tracked by a set of anisotropic magnetoresistive (AMR) sensors
- Collaborating with RISE Research Institute of Sweden to determine minimum magnet size feasible and sensor layout for PFIR
- PFIR implementation:
 - Single magnet tracer
 - Sensors to cover planes between reactor zones
 - Track tracer magnet as it passes each plane
 - Log time in each reactor



Magnetic Particle Tracking

Advantages

- Well developed technique
- Can measure both position and orientation of magnet, given enough sensors are present
- Can be used for mixing studies with enough sensors

Challenges

- Tracer particle must be a magnet; challenging to match fluidization behaviour of bed material
- Limited sizes of magnets commercially available
- Segregation of the tracer particle likely
- Commercially available systems not compatible with small magnets required



Radioactive Particle Tracking

- Radioactive material is tracked using multiple scintillation detectors to detect gamma rays from decay of tracer
- Collaborating with University of British Columbia on calibration techniques
- PFIR implementation:
 - Single radioactive tracer
 - Sensors to cover planes between reactor zones
 - Track tracer as it passes each plane
 - Log time in each reactor



Radioactive Particle Tracking

Advantages

- Well developed technique
- Tracer can be tailored to match bed material fluidization behavior
- Commercially available sensors
- Can be used for mixing studies with enough sensors

Challenges

- Difficult to separate out tracer particle in-situ
- Dense bed material may result in limited signal strength due to attenuation
- Requirement to source and handle radioactive tracer



Current Status & Future Work

- Status:

- Cold flow model under construction, testing to start in late summer
- Inductance particle tracking with PCB coils to continue development, however not planned to be used in first tests in the cold model
- Magnetic particle tracking for PFIR in development in collaboration with RISE Research Institutes of Sweden
- Radioactive particle tracking for PFIR in development in collaboration with the University of British Columbia

- Future work:

- Measure circulations rates with both RPT and MPT in the same test unit
- Develop data workflows to use radioactive and magnetic tracking data to validate CPFD models



Thank you!

For further information, please contact:

Scott Champagne

scott.champagne@canada.ca



Canada

© Her Majesty the Queen in Right of Canada, as represented by the Minister of Natural Resources, 2021



Natural Resources
Canada

Ressources naturelles
Canada

Canada