
Characterization of Solid Sorbent for Direct Air Capture of CO₂ Using a CFD-Based Methodology



Hossain Aziz

Research Scientist, NETL Support Contractor





This project was funded by the United States Department of Energy, National Energy Technology Laboratory, in part, through a site support contract. Neither the United States Government nor any agency thereof, nor any of their employees, nor the support contractor, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process, or service by trade name, trademark, manufacturer, or otherwise does not necessarily constitute or imply its endorsement, recommendation, or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.





Hossain Aziz^{1,2}; Subhodeep Banerjee^{1,2}; Bryan Hughes^{1,2}; Mehrdad Shahnam¹

¹National Energy Technology Laboratory, 3610 Collins Ferry Road, Morgantown, WV 26505, USA
²NETL Support Contractor, 3610 Collins Ferry Road, Morgantown, WV 26505, USA



- NATIONAL ENERGY TECHNOLOGY LABORATORY
- Started with an aminated PIM sorbent PF-15-TAEA developed by the NETL Integrated Project team
- PIM sorbent available in various form factors (particle and/or fiber)
- Intrinsic kinetics identified from mg-scale samples are not applicable at reactor scale
- Develop a laboratory-scale experiment in MFAL to investigate sorbent performance in a fixed bed configuration with active flow
- Calibrate sorbent kinetics using a CFD model of a small fixed bed reactor

Laboratory-scale experiments and CFD models NETL sorbents

Validate CFD modeling approach and model parameters Use CFD models to scale up DAC based on NETL sorbents


Small pilot scale: include ducting, fan, regeneration

Optimize performance



Small-Scale Fixed Bed Testing







Porous Media Model Solution Approach




- A CFD model is developed for the small-scale fixed bed using the porous media model approach in Ansys Fluent
- A porosity of 0.56 ($\varepsilon_s = 0.44$) is specified for the fixed bed
- Both the equilibrium adsorption $n^* = f(P,T)$ and the dynamic/instantaneous adsorption n are stored in user-defined memory and explicitly updated every time step
- Mass source term accounts for depletion rate of gas-phase CO₂ due to adsorption $S_m = -(\varepsilon_s \rho_s)(MW_{\rm CO2})(dn/dt)$
- Energy source term depends on the mass source and accounts for heat of adsorption

$$S_h = -\frac{[\Delta H][S_m]}{[MW_{CO2}]}; \quad \Delta H \equiv \text{Heat of adsorption}$$



Porous Media Method Pressure Drop Calibration





ΔP = 652.38 Pa

ΔP = 745.12 Pa

• Coeff. of viscous resistance = $5.11 \cdot 10^8 [1/m^2]$

• Coeff. of inertial resistance = $1.25 \cdot 10^4$ [1/m]




ΔP = 1470.42 Pa

Isotherm Fit for Adsorption of CO₂ from Dry Air



$$q_e = \frac{q_{max} K_{eq} C_{\text{CO}_2}^n}{1 + K_{eq} C_{\text{CO}_2}^n}$$


- Langmuir-Freundlich isotherm parameters q_{max} , K_{eq} , and n can be determined from isotherm data at different temperatures
- By considering these as exponential functions of temperature, a single-equation fit is generated that can be implemented into the CFD code



9

Dry Adsorption Rate Calibration

- Adsorption of CO_2 from dry air is modeled using the second-order linear driving force model with q_e implemented based on the isotherm
- CFD simulations were performed with different values of k at 500 ppm CO₂ and T = 22°C to match the experimental condition
- The effect of k on the breakthrough time underlines the methodology for calibrating k against the experimental data; k = 0.00861 (g-sorbent/g-CO₂)/s produces the best match for the range of flow rates studied





Time = 1.00 [s]

0.0098

0.0087

0.0076



- Equilibrium CO₂ capacity increases as a result of humidity in air but H_2O adsorption is generally unaffected by the presence of CO₂
- Stampi-Bombibelli et al.1 used the first-order linear driving force model to investigate co-adsorption of CO_2/ $\rm H_2O$

$$\frac{dq_{t,CO_2}}{dt} = k_{CO_2} (q_{e,CO_2} - q_{t,CO_2}); \quad \frac{dq_{t,H_2O}}{dt} = k_{H_2O} (q_{e,H_2O} - q_{t,H_2O})$$

- Appropriate isotherm models must be used for q_{e,CO_2} and q_{e,H_2O} in co-adsorption conditions
- Most of the heat released during co-adsorption of CO_2/H_2O is due to H_2O adsorption; since H_2O is present in higher concentrations compared to the ppm levels of CO_2 , accurate representation of the isosteric heat of adsorption becomes important


¹ V. Stampi-Bombibelli, M. vab der Spek, M. Mazotti, Analysis of direct capture of CO2 from ambient air via steam-assisted temperature vacuum swing adsorption, Adsorption, 2020, 26, 1183–1197.



Modified Setup for Humid Adsorption



• The small-scale fixed bed setup was modified to incorporate a bubbler for experimental breakthrough testing with humid air






Humid Adsorption Breakthrough Results



• Breakthrough testing is conducted with dry and humid air at different flow rates




- Repeats runs at the same flow rate show comparable breakthrough profiles
- The breakthrough curve rises faster with increased flow rate since more CO₂ is available relative to the capacity
- The breakthrough curve rises slower with humid air indicating larger capacity
- MFAL breakthrough profiles are used to calibrate $k_{\rm CO_2}$ in the fixed bed configuration only, not to measure uptake capacity; $q_{e,\rm CO_2}$ in co-adsorption CFD model is affixed based on data from NETL Integrated Project colleagues



Effect of Humidity on H₂O Uptake Capacity



- Experimental data provided by Integrated Project colleagues is used to fit a Henry's Law relationship between $q_{e,\mathrm{H_20}}$ and relative humidity (RH)
- Rate constant $k_{\rm H_20}$ is assumed constant since RH is being varied at constant temperature
- The data fit corresponds to a Henry's Law constant of 0.1736 wt.%/RH
- This allows H₂O uptake capacity to be incorporated into the CFD model as a continuous function of humidity





Modeling CO₂ Adsorption from Humid Air




- CFD model for dry adsorption was extended to model the co-adsorption of CO_2/H_2O
- CFD simulations were performed at different values of k at inlet flow rate of 2.8 slpm with 500 ppm CO₂ and 40% RH at T=25°C

$$\frac{dq_{t,CO_2}}{dt} = k_{CO_2} (q_{e,CO_2} - q_{t,CO_2}); \quad \frac{dq_{t,H_2O}}{dt} = k_{H_2O} (q_{e,H_2O} - q_{t,H_2O})$$

 $q_{e,CO_2} = 1.31 \text{ mmol}-CO_2/g$ -sorbent at 25°C from Micromeritics BTA


 $q_{e,H_20} = 0.1736 \cdot \text{RH}(\%), k_{H_20} = 0.001366 \text{ s}^{-1}$




Modeling CO₂ Adsorption from Humid Air



• Rate constant values cannot be compared directly for sorbents with different uptake capacities; for side-by-side comparison of the kinetics for CO₂ adsorption from dry and humid air, the






- CO₂ adsorption from humid air starts out 1% faster and the difference grows over time (+1% after 200 s)
- Current iteration of PF-15-TAEA has up to 25% increased capacity and will require a repeat
 of the sorbent characterization methodology



Ongoing/Future Work: Scale-up to Bench Scale









Ongoing/Future Work: Scale-up to Bench Scale




- Adsorption experiments in the bench-scale setup was conducted at MFAL by Integrated Project colleagues
- The CFD model of the small-scale fixed bed will be scaled up and validated against experimental bench-scale data
- In turn, the validated CFD model will be used to optimize bed design and operating conditions for best capture/pressure drop performance
- The rate calibration regimen may need to be repeated if significant changes to sorbent form factor or operating conditions occur



Ongoing/Future Work: Modeling of Fiber Shaped Sorbents



- PF-15-TAEA is currently available in different form factors, solid fibers, hollow fibers, and flat sheet with different uptake and kinetics properties
- Porous media model approach may not be appropriate to model the flow through the flat sheet arrangement because of non-uniform distribution of porosity
- To accurately predict pressure drop across the flat sheet, a CFD–DEM coupled simulation is developed in Ansys Rocky coupled with Ansys Fluent
- The flexible fibers are modeled by connecting multiple sphero-cylinders serially through virtual bonds¹




¹ Y. Guo, C. Wassgren, J. S. Curtis, D. Xu, A bonded sphero-cylinder model for the discrete element simulation of elasto-plastic fibers, Chemical Engineering Science, 2018, 175, 118–129.




Ongoing/Future Work: Modeling of Fiber Shaped Sorbents



- The curved/deformed shape is generated because of the relative movement between sphero-cylinder elements
- The bond forces can be calculated using different models, e.g. linear elastic, bilinear elastoplastic, model, linear elastic & viscous damping, etc.
- Further sensitivity studies are necessary to develop an accurate representation of the flat sheet form factor in the coupled CFD-DEM model






Deposition of multi-element flexible fibers on obtained from simulation



Ongoing/Future Work: Modeling of Fiber Shaped Sorbents



- The CFD-DEM model is used to analyze pressure drop across a representative fiber mat
- Fibers are deposited on a horizontal plane halfway up the 11.4 x 11.4 x 4.06 cm domain
 - Inlet air velocity = 2 m/s
 - Fiber diameter = 0.7 mm
 - Fiber length = 24.05 mm
 - Fiber element length = 1.85 mm (13 elements/fiber)
 - Drag law proposed by Marheineke & Wegener¹ was used to model the drag force



¹ N. Marheineke, R. Wegener, Modeling and application of a stochastic drag for fibers in turbulent flows, International Journal of Multiphase Flow, 2011, 37, 136-148.



NETL Resources

VISIT US AT: www.NETL.DOE.gov



@NationalEnergyTechnologyLaboratory

CONTACT: Hossain Aziz <u>Hossain.aziz@netl.doe.gov</u>

